

# Evaluation of Milk Laboratories

**2009 Revision**



U.S. Department of Health and Human Services  
Public Health Service  
Food and Drug Administration

## **PREFACE**

In 1941 the United States Public Health Service began evaluations of the facilities, procedures and techniques of analysts in state and local milk laboratories doing official analysis. In 1977, the Food and Drug Administration (FDA) and 46 States had programs for measuring analyst performance in official and officially designated milk laboratories, by on-site evaluations of techniques and proficiency testing. Today all 50 States, Puerto Rico and the Virgin Islands participate in the National Conference on Interstate Milk Shipments (NCIMS) Milk Laboratory Program. These evaluations have resulted in greater uniformity, accuracy and precision of microbiological and chemical analysis.

The material in this publication provides the procedures for the evaluation of milk laboratories required to meet the sanitation standards of current in use edition of the Grade 'A' Pasteurized Milk Ordinance (PMO).

The information in this booklet was revised by the Food and Drug Administration Laboratory Proficiency Evaluation Team (FDA/LPET) in conjunction with the NCIMS and its Laboratory Committee. The basic responsibility for preparation of this revision was assumed by the Food and Drug Administration, Center for Food Safety and Applied Nutrition, Office of Food Safety, Division of Food Processing Science and Technology, Laboratory Proficiency and Evaluation Team, HFH-450, 6502 South Archer Road, Summit-Argo, IL 60501, USA (Telephone (708) 728-4114; Fax (708) 728-4179), hereafter referred to as FDA/LPET.

# TABLE OF CONTENTS

	<i>Page</i>
<b>INTRODUCTION</b> .....	1
<b>SECTION 1: LABORATORY EVALUATION PROGRAMS</b> .....	3
CERTIFICATION/APPROVAL OF MILK LABORATORY ANALYSTS .....	3
ACCREDITATION/APPROVAL OF MILK LABORATORIES .....	5
APPROVAL OF INDUSTRY ANALYSTS/INDUSTRY SUPERVISORS .....	6
APPROVAL OF BACTOSCAN INDUSTRY OPERATORS .....	8
<b>SECTION 2: PROFICIENCY TESTING PROGRAMS</b> .....	9
SPLIT SAMPLES - MICROBIOLOGY .....	9
SPLIT SAMPLE ANALYSIS .....	10
ANALYSTS PERFORMANCE LEVEL .....	11
SPLIT SAMPLES - CHEMISTRY .....	13
VITAMINS .....	13
WATER MICROBIOLOGY .....	14
SPLIT SAMPLE ANALYSIS .....	14
LABORATORY PERFORMANCE LEVEL .....	15
<b>SECTION 3: CERTIFICATION OF LABORATORY EVALUATION OFFICERS</b> .....	16
<b>SECTION 4: EQUIPMENT AND APPARATUS OF AID TO EVALUATION OFFICERS</b> .....	18
<b>SECTION 5: GUIDELINES FOR CONDUCTING LABORATORY EVALUATIONS.</b>	19
<b>SECTION 6: LABORATORY EVALUATION REPORTS</b> .....	22
EVALUATION FORMS .....	22
NARRATIVE REPORT .....	22
CONCLUSIONS .....	23
<b>REFERENCES</b> .....	24
<b>TABLE 1: SPLIT SAMPLE COMPOSITION</b> .....	25
<b>TABLE 2: STATISTICAL LIMITS</b> .....	26
<b>TABLE 3: MAXIMUM NUMBER OF UNACCEPTABLE RESULTS</b> .....	26
<b>NARRATIVE REPORT FORMS</b> .....	27

# **EVALUATION OF MILK LABORATORIES**

## **2009 Revision**

### **INTRODUCTION**

Official accreditation of milk laboratories and Certified Industry Supervisors (CIS) requires that the appropriate federal or state milk laboratory control agency conduct an on-site survey to determine satisfactory performance of analysis in milk laboratories and performance of analysis by CIS in facilities where the examinations, required by the *Grade 'A' Pasteurized Milk Ordinance* (PMO), are performed. In addition, satisfactory performance in the analysis of annual proficiency test samples must be demonstrated. An accredited milk laboratory may be an approved official or officially designated milk laboratory under the administrative control of a federal, state or local regulatory authority. Approval of Industry Supervisors (IS) and Industry Analysts (IA) requires verification of proficiency in performing drug residue analysis at least biennially, through on-site performance evaluation and/or analysis of split samples or by other means as noted in SECTION 1 below.

The State Laboratory Evaluation Officer (State LEO) will use the appropriate FDA-2400 Series Forms when evaluating official laboratories, officially designated laboratories, CIS, IS and IA. Appropriate FDA-2400 Series Forms are those forms that have been approved by the NCIMS Laboratory Committee working cooperatively with the FDA and the NCIMS executive board, and are effective 90 days after executive board approval.

**Official Laboratory:** An official laboratory is a biological, chemical or physical laboratory which is under direct supervision of the state or a local regulatory agency.

**Officially Designated Laboratory:** An officially designated laboratory is a commercial laboratory authorized to do official work by the regulatory agency, or a milk industry laboratory officially designated by the regulatory agency for the examination of producer samples of Grade 'A' raw milk for pasteurization and commingled milk tank truck samples of raw milk for drug residues.

**Certified Industry Supervisor (CIS):** An industry supervisor who is evaluated and listed by a State LEO as certified to conduct drug residue screening tests at industry drug residue screening sites for PMO, Appendix N regulatory actions (confirmation of tankers, producer trace back and/or permit actions).

**Industry Supervisors (IS):** An individual trained by the State LEO who is responsible for the supervision and training of industry analysts who test milk tank trucks for Appendix N drug residue requirements.

**Industry Analyst (IA):** A person under the supervision of the CIS or IS who is assigned to conduct screening of milk tank trucks for Appendix N drug residue requirements.

**BactoScan Industry Operator (BIO):** A person who operates a BactoScan FC under the supervision of a certified BactoScan analyst and analyzes samples for regulatory compliance.

Food and Drug Administration (FDA) laboratory accreditation procedures provide a national base for the uniform collection and examination of milk, in compliance with the sanitation standards of the PMO.

Uniform accreditation of milk laboratories is maintained by the following two functions:

1. FDA accreditation of state central milk laboratories and certification of analysts is based on (a) satisfactory triennial on-site evaluations of laboratory facilities, equipment, records, and analyst performance of techniques, and (b) satisfactory annual proficiency testing (the examination of split milk samples) to continuously appraise analyst performance.
2. FDA certification of State LEOs who (1) accredit local laboratories and certify analysts and CIS based on (a) satisfactory biennial on-site evaluations of laboratory facilities, equipment, records and analyses and (b) satisfactory annual proficiency testing which meets established national standards and (2) approve IS and IA (who only screen for drugs) based on (a) verification that each IS has been trained (by conducting required workshops for all industry supervisors) and has established a program that ensures the proficiency of the IA they supervise, (b) verification that each IS and IA has demonstrated proficiency in performing drug residue analysis at least biennially. Verification of proficiency may include an analysis of split samples and/or an on-site performance evaluation or another proficiency determination that the State LEO and the FDA/LPET agree is appropriate. (PMO, Appendix N)

## **SECTION 1: LABORATORY EVALUATION PROGRAMS**

An evaluation of a milk laboratory must include an on-site visit to the laboratory, a review of the records, including training records of IAs, records of split sample performance, facilities, equipment, materials and procedures. The evaluation shall be made using the most recent approved Official Milk Laboratory Evaluation Forms (FDA-2400 Series Forms). The Federal or State LEO shall determine if the laboratory facilities, equipment, records and techniques of analysts are in compliance with the FDA-2400 Series Forms and where appropriate the latest edition of *Standard Methods for the Examination of Dairy Products*<sup>1</sup> (SMEDP).

A copy of the “Grade ‘A’ Milk Laboratory Evaluation Request and Agreement Form” (see page 19) must be signed by a representative of the facility prior to initiation of the survey. This document must be maintained on file by the State LEO.

A set of completed evaluation forms shall accompany the narrative report which describes the degree of suitability of the laboratory facilities, equipment, records, the analysts’ procedures, and a statement as to whether the results of the analyst or CIS examinations are acceptable for use in rating milk for interstate shipments. The narrative report must be sufficiently detailed to allow readers to determine what is being cited without having to refer to the FDA-2400 Series Forms.

Survey reports of on-site evaluations of Official Milk Laboratories and CISs shall be sent within 60 days of the initial, biennial anniversary or supplemental date of the laboratory evaluation to the Official Milk Laboratory/CIS, the appropriate Food and Drug Administration Regional Office and the FDA/LPET. Reports can be submitted by traditional fashion (mail, common courier) or electronically. Reports to the Official Milk Laboratories /CIS must include copies of the completed FDA-2400 Series Forms and a copy of the narrative report. Reports to FDA Regional Office and FDA/LPET should only include the narrative report.

Survey reports of on-site evaluations of screening sites shall be sent to the facility within 60 days of the initial, biennial anniversary, or supplemental date of the laboratory evaluation.

### **CERTIFICATION/APPROVAL OF MILK LABORATORY ANALYSTS**

Certification of milk laboratory analysts by the Federal or State LEO shall be based on the following criteria:

1. State central milk laboratories’ evaluations shall be scheduled and performed by their triennial expiration date. State central milk laboratories shall submit requests, in writing, for on-site evaluation of new analyst(s) performance of techniques, new methods and/or new facilities to the FDA/LPET. The FDA/LPET shall schedule a mutually agreeable date or a date within 60 days of the request for an evaluation.
2. Evaluations of milk laboratories within a state shall be scheduled and performed by their biennial expiration date. Milk laboratories within a state shall submit requests, in writing, for on-site evaluation of new analyst(s) performance of techniques, new methods and/or new

facilities to the State LEO. The State LEO shall schedule a mutually agreeable date or a date within 30 days of the receipt of the request for an evaluation.

3. The laboratory facilities, equipment and records shall meet the requirements stated on the FDA-2400 Series Forms, and where appropriate SMEDP, as determined by an on-site evaluation.
4. Analyst performance is in compliance during an on-site evaluation, with procedures required by the FDA-2400 Series Forms, PMO, and where appropriate SMEDP.
5. Analysts meet the performance levels of the proficiency testing program (SECTION 2). The State LEO may issue a certificate of approval to each laboratory analyst who meets the stated criteria in numbers 3 and 4 above. The certificate, if issued, shall indicate the specific laboratory procedure(s) for which he or she is certified or approved.
6. Vitamin testing laboratories have submitted satisfactory quality control information, use methods acceptable to the FDA or other official methodologies which give statistically equivalent results to the FDA methods, have one or more certified analysts who have satisfactorily participated in the vitamin split sample program and have met performance levels of the proficiency testing program (SECTION 2).

Analysts seeking certification or approval who are employed in laboratories not previously approved, or laboratories that have lost accreditation or approval and are seeking Recertification, may be approved to conduct official examinations only if criteria 3 and 4 are met. When such analysts successfully complete the next official proficiency tests administered by the State LEO, a certificate of approval may be issued to such analyst. If such analyst does not successfully meet the performance levels of the proficiency testing program, the approval to conduct official examinations shall be withdrawn.

When a new analyst is assigned to an accredited laboratory between on-site evaluations, conditional approval status will be provided to the new analyst upon satisfactory completion of criteria 4 or 5. Full certification will follow after acceptable completion of both criteria 4 and 5. Conditionally approved analysts failing to meet the established applicable criteria of laboratory performance during an on-site laboratory evaluation will have their conditionally approved status revoked.

The CIS and certified analysts must participate, at least annually, in proficiency testing (the examination of milk split samples) for those specific procedures for which they are certified. Failure without cause to participate in the annual split sample evaluation or failure to meet established satisfactory performance criteria will result in the CIS or certified analyst(s) having their certification status downgraded from full to provisional. Failure of provisionally certified analyst or CIS to participate in the examination of or to meet established satisfactory performance levels on the next set of split samples will result in withdrawal of certification.

A CIS or certified analyst that loses certification for one or more tests cannot examine official samples using a test for which certification was withdrawn. Recertification procedures are shown in “SECTION 2: PROFICIENCY TESTING PROGRAMS”.

Copies of notices of changes of certification or revocation of certification shall be sent to the laboratory or facility involved, the milk regulatory agency, the state milk sanitation rating agency, the appropriate FDA Regional Office and the FDA/LPET.

Upon notice of revocation, the certificate, if issued, shall be returned to the issuing State LEO within 90 days.

### **ACCREDITATION/APPROVAL OF MILK LABORATORIES**

Accreditation or approval of milk laboratories by federal or state milk laboratory control agencies shall be based on meeting the following requirements:

1. The laboratory facilities, equipment, procedures and records must meet the requirements stated on the appropriate FDA-2400 Series Forms and for CIS, appropriate Appendix N 2400 Series Forms, as determined by an on-site evaluation.
2. All official examinations required by the PMO must only be performed by certified analysts or CIS.
3. Vitamin testing laboratories have submitted satisfactory quality control information, use methods acceptable to the FDA or other official methodologies which give statistically equivalent results to the FDA methods, have one or more certified analysts who have satisfactorily participated in the vitamin split sample program and have met performance levels of the proficiency testing program (SECTION 2).

The State LEO may issue a certificate of accreditation or approval to each official, commercial, and industry laboratory meeting criteria 1 and 2 above. The certificate shall be valid for 2 years unless revoked.

When an accredited laboratory changes location or undergoes substantial remodeling, an evaluation of the new laboratory or screening facility is required within 3 months. No evaluation of personnel or procedures is required at this time.

For initial accreditation, milk laboratories shall have a minimum of 15 days of required records available at the time of the on-site evaluation. The laboratory has records to show that all necessary quality control requirements have been performed and are satisfactory, and that there are 15 days of records to demonstrate that critical equipment is functional.

When a certified analyst or CIS leaves an accredited laboratory, the laboratory/facility manager must notify the State LEO immediately since the loss of a certified analyst may result in the loss of certification for one or more procedures, or may result in the loss of the laboratory's accreditation. For example, a laboratory having only one certified analyst will lose accreditation.



Official examinations cannot be conducted at non-accredited laboratories. When a laboratory or CIS facility loses its accreditation because of lack of certified analysts, or for some other reason, the Federal or State LEO shall immediately notify the milk laboratory involved, the state milk regulatory agency, the state milk sanitation rating agency, any out-of-state milk regulatory agencies where known customers are located, the appropriate FDA Regional Office and the FDA/LPET, by a letter of notification to be dated within five (5) working days of the loss of accreditation.

Laboratories requesting withdrawal of accreditation shall notify the State LEO in writing. Upon receipt of the written request, the State LEO shall immediately notify the state milk regulatory agency, the state milk sanitation rating agency, any out-of-state milk regulatory agencies where known customers are located, the appropriate FDA Regional Office and the FDA/LPET by a letter of notification to be dated within five (5) working days of receipt of the written request. Upon notice of withdrawal of accreditation, the certificate, if issued, shall be returned to the issuing State LEO within 90 days.

Additionally, the laboratory shall notify its customers in writing, that it has withdrawn or been decertified and shall not represent itself as an official laboratory or officially designated laboratory, for those decertified or unapproved procedures under the agreements of the NCIMS. A copy of the generic notification must be sent to the State LEO. Decertification will remain in effect until measures are taken by the laboratory to attain compliance and another survey is completed successfully.

#### **APPROVAL OF INDUSTRY ANALYSTS/INDUSTRY SUPERVISORS**

Approval of Industry Supervisors (IS) and Industry Analysts (IA) by the State LEOs shall be based on meeting all of the following requirements:

1. The laboratory facilities, equipment, procedures and records meet the requirements stated on the approved 2400 Series Forms associated with the Appendix N program.
2. All screening tests required by the PMO, Appendix N must only be performed by approved IS, IA or by a certified entity.
3. Analyst performance is in compliance with procedures required by the approved FDA-2400 Series Forms associated with the Appendix N program.
4. The analyst meets the performance levels of the proficiency testing program (the examination of milk split samples)
5. Approval of IS and IA require verification of proficiency in performing drug residue analyses at least biennially, through on site performance evaluation and/or analysis of split samples, or another proficiency determination that the State LEO and the FDA/LPET agree is appropriate. (PMO, Appendix N)

6. The IS has attended and received training by the State LEO. This training must be documented.

The IS shall report to the State LEO the result of all competency evaluations performed by IA. The name of each IS and IA (as well as their training and evaluation status) shall be maintained by the State LEO and updated as replacement, additions and/or removals occur. The State LEO shall verify (document) that each IS has established a program that ensures the proficiency of the IA they supervise. The State LEO shall also verify that each IS and IA has demonstrated proficiency in performing drug residue analysis at least biennially. Verification may include an analysis of split samples and/or an on-site performance evaluation or another proficiency determination that the State LEO and the FDA/LPET agree is appropriate.

When a new analyst is assigned to an approved laboratory, conditional approval status will be provided to the new analyst upon satisfactory demonstration of competency to the IS. Full approval status will follow after verification of proficiency (see criteria #5, above). Conditionally approved analysts failing to meet the established applicable criteria of laboratory performance during an on-site laboratory evaluation or analysis of split samples will have their conditionally approved status revoked.

Fully approved analysts failing to meet the established applicable criteria of laboratory performance during an on-site laboratory evaluation or analysis of split samples will have their fully approved status downgraded to “provisional”. Provisionally approved analysts failing to meet the established applicable criteria of laboratory performance during an on-site laboratory evaluation or analysis of split samples will have their provisionally approved status revoked.

Failure by the IS or the IA to demonstrate adequate proficiency to the State LEO shall lead to their removal from the State LEO list of IS/IA. Re-instatement of their testing status shall only be possible by completing retraining and/or successfully analyzing split samples and/or passing an on-site evaluation or otherwise demonstrating proficiency to the State LEO. Analysts not on the State LEO list of Approved IS/IA are not approved to test bulk milk in the Appendix N program.

When a screening facility loses its approval because of lack of approved IS or IA, or for some other reason, the State LEO shall immediately notify the screening facility involved, the state milk regulatory agency, the state milk sanitation rating agency, any out-of-state milk regulatory agencies where known customers are located, the appropriate FDA Regional Office and the FDA/LPET, by a letter of notification to be dated within five (5) working days of receipt of the loss of approval.

Screening facilities requesting withdrawal of approval shall notify the State LEO in writing. Upon receipt of the written request, the State LEO shall immediately notify the state milk regulatory agency, the state milk sanitation rating agency, any out-of-state milk regulatory agencies where known customers are located, the appropriate FDA Regional Office and the FDA/LPET by a letter of notification to be dated within five (5) working days of receipt of the written request.

Additionally, the screening facility shall notify its customers in writing that it has been withdrawn or has lost its approval and shall not represent itself as an approved screening facility under the agreements of the NCIMS. A copy of the generic notification must be sent to the State LEO. Loss of approval will remain in effect until measures are taken by the screening facility to attain compliance and another survey is completed successfully.

### **APPROVAL OF BACTOSCAN INDUSTRY OPERATORS**

Approval of BactoScan Industry Operators (BIO) shall be based on meeting the following requirements:

1. The industry operator must complete the BIO operating protocols, training and oversight specified in the training procedure document.
2. The laboratory must maintain one certified BactoScan analyst (see current FDA 2400 series form) for training and ongoing oversight of the BIO.
3. Refer to the BIO approved training procedures at the end of the BactoScan FDA 2400 series form.
4. The BIO meets the performance levels of the proficiency testing program (the examination of milk split samples)
5. Records are to be maintained for BIO oversight.

NOTE: A BIO can analyze samples for regulatory compliance.

## **SECTION 2: PROFICIENCY TESTING PROGRAMS**

### **SPLIT SAMPLES - MICROBIOLOGY**

The Food and Drug Administration shall split samples annually with all federally certified analysts of each State/Territory (hereafter noted as State) central accredited milk laboratory. State milk laboratory control agencies shall split samples at least annually with all state certified analysts of each official, officially designated accredited milk laboratory, and all CIS. State milk laboratory control agencies shall verify that each IS and IA has demonstrated proficiency in performing drug residue analysis at least biennially through on-site performance evaluation and/or analysis of split samples, or another proficiency determination that the State LEO and the FDA/LPET agree is appropriate.

State milk laboratory control agencies having less than 10 analysts (total) in their milk laboratory program are to develop joint state proficiency testing programs with other states which can meet the criteria for certification of analysts and accreditation of laboratories. In cases where a minimum number of analysts ( $\geq 10$ ) are not available, evaluation of proficiency will be made by a determination that the State LEO and the FDA/LPET agree is appropriate.

An acceptable annual proficiency testing program shall meet the following applicable criteria:

1. When an analyst examines both raw milk for pasteurization and pasteurized milk and milk products, a minimum of twenty-two (22) samples shall be examined by the analyst using those procedures for which the analyst has been approved unless excused for due cause. The laboratory tests, categories, types and recommended duplicates of milk products are shown in Table 1, page 25.
2. When an analyst examines only raw milk for pasteurization, a minimum of fourteen (14) samples shall be examined by the analyst using those procedures for which the analyst has been approved unless excused for due cause. The laboratory tests and recommended duplicates of samples are shown in Table 1, page 25.
3. When an analyst examines only pasteurized milk and milk products, a minimum of sixteen (16) samples shall be examined by the analyst using those procedures for which the analyst has been approved unless excused for due cause. The laboratory tests and recommended duplicates of samples are shown in Table 1, page 25.
4. When a CIS examines bulk milk tanker milk or its equivalent for Appendix N purposes, a minimum of eight (8) samples shall be analyzed utilizing the test kit(s) for which that CIS is certified or approved, or for which the CIS is seeking certification. In general, the milk samples shall consist of the members of the beta-lactam family, at the safe/tolerance levels, which the test kit(s) is designed to detect as well as milk samples containing no animal drug residues. The CIS may misidentify one of the samples and maintain and/or gain certification. If more than one sample is misidentified, the CIS falls one level of certification. If this occurs twice consecutively, the CIS is no longer certified or approved (rules for Recertification of laboratories apply).

5. When an IS or an IA examines bulk milk tanker milk or its equivalent for Appendix N purposes, a minimum of eight (8) samples shall be analyzed utilizing the test kits for which that IS or IA is approved or for which the IS or IA is seeking approval. In general, the milk samples shall consist of members of beta-lactam family, at the safe/tolerance levels, which the test kits are designed to detect as well as milk samples containing no animal drug residues. The IS or IA may misidentify one of the samples and maintain and/or gain approval. If more than one sample is misidentified, the IS or IA falls one level of approval. If this occurs twice consecutively, the IS or IA is no longer approved. Re-instatement of their testing status shall only be possible by completing retraining and/or successfully analyzing split samples and/or passing an on-site evaluation or otherwise demonstrating proficiency to the State LEO.
6. Each analyst certified to perform visual drug residue tests will participate in annual proficiency tests to demonstrate ability to detect the beta-lactams at safe/tolerance level per kit label claim (Penicillin G, Cloxacillin, Cefotiofur, and Cephapirin) using blind samples with duplicate negatives. A minimum of six (6) samples may be used. However, with six (6) samples ALL results must be correct. If eight (8) samples are used, an analyst/CIS may miss one (1) and still pass the proficiency test.
7. An acceptable annual proficiency testing program for the BactoScan FC (all NCIMS approved models), shall meet the following applicable criteria.
  - (a) The BactoScan FC (all NCIMS approved models) shall be used to examine a minimum of fourteen (14) samples and be operated by a certified analyst or an approved BIO using the procedures approved to operate the BactoScan FC and for which the analyst or BIO has been certified/approved, respectively.
  - (b) Split samples (minimum of 14) shall be made up using BactoScan FC Blank solution and BactoScan FC Bacteria Control Samples.
  - (c) Value ranges (count ranges) and dilutions shall be made to achieve the levels as set by the FDA. Recommended duplicates of samples are shown in Table 1, page 25.

### **SPLIT SAMPLE ANALYSIS**

The Standard Plate Count (SPC), Petrifilm Aerobic Count (PAC), Plate Loop Count (PLC), BactoScan FC Count (BSC), Spiral Plate Count Method (SPLC), Direct Microscopic Somatic Cell Count (DMSCC), Electronic Somatic Cell Count (ESCC), Electronic Phosphatase Count and Vitamin A and D<sub>3</sub> result of each certified analyst shall fall within the limits shown in Table 2, page 26.

The steps for statistical analysis of split sample results are as follows:

1. A minimum of ten (10) results per sample per test is required for statistical analysis.
2. Calculate the logarithmic mean for the Standard Plate Count, Petrifilm Aerobic Count, Plate Loop Count, BactoScan FC Count (BSC), Spiral Plate Count Method (SPLC), Direct Microscopic Somatic Cell Count, Electronic Somatic Cell Count, Electronic Phosphatase

Count and Vitamin A and D<sub>3</sub> results of each test sample; using a table of common logarithms, list the logarithms of all analyst counts for a given sample. Calculate the mean of the logarithms for the sample.

3. Determine for each sample for each test whether there are results outside of the Rejection Limit (L<sub>1</sub>). Rejection results are identified by applying to each analyst's result the limit (sample mean  $\pm$  L<sub>1</sub>). Results falling outside the limit are classified as outliers and are unacceptable. Note, by sample and test, the analysts who have results outside of the limits.
4. Determine for each sample for each test whether there are analyst results outside of the Rejection Limit (L<sub>2</sub>). Remove unacceptable analyst result and re-compute the mean of each sample if results have been rejected in accordance with 3 above. If there are none, use the same means calculated in 2 or 3 above. Rejection results are identified by applying to each analyst's result the limit (sample mean  $\pm$  L<sub>2</sub>). Results falling outside the limit are classified as "out of limits" and are unacceptable. Note, by sample and test, the analysts who have results outside of these limits.
5. Using Table 3, page 26, list all analysts who have more than the maximum number of sample results per test classified as unacceptable by either the L<sub>1</sub> or L<sub>2</sub> or both limits.
6. Analysts certified for vitamin analysis shall meet the acceptance limits (L<sub>1</sub> and L<sub>2</sub>) and performance levels shown in Tables 2 and 3, page 26.
7. An acceptable annual proficiency testing program for the BactoScan FC Count (all NCIMS approved models), shall meet the following applicable criteria.
  - (a) The BactoScan FC Count (all NCIMS approved models) shall be used to examine a minimum of fourteen (14) samples and be operated by a certified analyst or an approved BIO using the procedures approved to operate the BactoScan FC Count and for which the analyst or BIO has been certified/approved, respectively.
  - (b) Split samples (minimum of 14) shall be made up using BactoScan FC Blank solution and BactoScan FC Count Bacteria Control Samples.
  - (c) Value ranges (count ranges) and dilutions shall be made to achieve the levels as set by the FDA. Recommended duplicates of samples are shown in Table 1 page 25.

### **ANALYST PERFORMANCE LEVEL**

Analysts certified to perform the examinations required by the "Grade 'A' PMO" shall meet the following performance levels on an annual basis.

1. Analysts certified to perform the Standard Plate Count, Petrifilm Aerobic Count, Plate Loop Count, BactoScan FC, Spiral Plate Count Method, Direct Microscopic Somatic Cell Count, Electronic Somatic Cell Count, Electronic Phosphatase Count and Vitamin A and D<sub>3</sub> analysis, and BIOs approved to operate a BactoScan FC shall meet the acceptance limits and performance levels shown in Tables 2 and 3, page 26.

2. Analysts certified to perform inhibitor tests shall detect samples that contain beta-lactam or other animal drug residues detectable by the appropriate official test for the drug and product. If using drug other than beta-lactam, samples must be spiked in duplicate. See Table 3, page 26.
3. Analysts certified to perform phosphatase tests shall detect samples that contain residual phosphatase detectable by appropriate official test methods. Analysts certified for Electronic Phosphatase Count methods shall detect samples that contain between 100 and 2,500 mU (the majority of values at the action level of 350 mU) within the specified limits in Table 2, page 26.
4. Analysts certified for the coliform procedure shall qualitatively detect and verify coliform organisms in samples containing at least five (5) but not greater than ten (10) coliform organisms per milliliter or gram of product. See Table 3, page 26.
5. Certified Industry Supervisors certified to perform Appendix N test(s) for beta-lactam drugs shall detect members of the beta-lactam family, at the safe/tolerance levels, which the test kit(s) is designed to detect. See Table 3, page 26.

Fully certified analysts not meeting the described performance levels shall be provisionally certified for the test procedure(s) in which they exceed the maximum number of unacceptable results on samples. Provisionally certified analysts can regain full certification status by meeting satisfactory performance levels on the next set of split samples. If a provisionally certified analyst does not meet satisfactory performance levels on the next set of split samples, certification to perform the specific test(s) will be withdrawn. An analyst who has lost certification may be required to participate in a training program acceptable to the milk laboratory certifying authority before requesting Recertification. Recertification after training shall be based on the analyst meeting the certification criteria described in SECTION 1: LABORATORY EVALUATION PROGRAMS. A certified analyst may only become conditionally approved again by the route by which he/she lost certification, i.e. if the analyst lost certification due to failure on milk split samples then he/she can only become conditionally certified by passing the next set of milk split samples. If the analyst failed an on-site evaluation that leads to his/her loss of certification then he/she must pass the next on-site certification to become conditionally certified.

BactoScan Industry Operators performance levels shall follow the performance procedures indicated above for fully certified analysts.

Copies of the proficiency testing report, including tabulation of analyst results, shall be sent within four (4) months of the split sample examination date to the participating laboratory, the appropriate FDA Regional Office, and the FDA/LPET.

## **SPLIT SAMPLES – CHEMISTRY**

### **VITAMINS**

The Vitamin Proficiency Test Program is operated by the FDA/LPET. In order to be accredited and be listed, laboratories must have analysts who have satisfactorily participated in at least two consecutive split sample analyses and must have submitted satisfactory method validation and quality control/quality assurance (QC/QA) information. Participation in proficiency testing alone does not satisfy the criteria for analyst certification and laboratory accreditation.

The Grade A Vitamin Proficiency Testing Program involves the analysis of sets of four samples sent to participating laboratories every four (4) months, i.e., three times a year with a total of twelve (12) samples. Certification status is based in part on the ability of analysts to analyze samples and have their results fall within limits ( $L_1=0.300$  and  $L_2=0.200$ , based on the statistical parameters set at the 1995 NCIMS Conference in St. Louis, MO). Conditional certification is granted to an analyst (not to a laboratory) when the analyst has satisfactorily analyzed two sets of samples (eight (8) samples in two consecutive shipments). Analysts may have one (1) unsatisfactory result, i.e., miss (out of limits) one sample, and still be considered as having satisfactory performance. After analyzing the next consecutive set of samples the analyst is considered fully certified if no more than 2 samples have been missed over the course of a one year period (twelve (12) consecutive samples analyzed).

Once fully certified, analysts maintain certification by satisfactorily analyzing all three (3) sets of split samples each year. During the course of the year full certification is maintained if no more than two samples (of 12) are missed. Failure without cause to analyze all twelve (12) samples during the course of the year will result in the down grading of an analyst's status. It is imperative that laboratory schedules be set up to allow for the analysis of these samples. If a fully certified analyst misses more than two samples (of 12) then that analyst will be down graded to provisional certification. Full certification will be regained if that analyst misses no more than one sample of the next eight (8) that he/she analyzes. Provisionally or conditionally certified analysts that miss more than one (1) sample in the next eight samples analyzed after receiving the respective status will have certification/approval removed.

Once certification/approval is removed an analyst may only regain conditional certification by satisfactory performance on the next eight samples, i.e., miss no more than one (1) sample. Full certification requires that the analyst meet the criteria described above.

For split sample purposes each analyst must independently analyze the samples. Routine analysis may be performed by multiple analysts working together or by partitioning duties. Certified analysts are responsible for conducting official analysis. Non certified analysts may assist in analysis but may not solely perform official analyses or report official results.

Re-entry of laboratories that have voluntarily withdrawn or laboratories that have had their accreditation removed is subject to meeting all requirements needed from a new laboratory, including all quality control (QC) information. It is the responsibility of the laboratory to inform the FDA/LPET when a certified analyst is no longer employed at that laboratory. A laboratory



that loses all of their certified analysts is no longer accredited to do official work and must seek new laboratory entry prior to resuming official analysis.

An acceptable annual proficiency testing program shall consist of the analyst examining pasteurized milk and milk products for Vitamins A and D<sub>3</sub>, a minimum of four (4) samples three (3) times a year for a total of twelve (12) samples annually using the methods developed by the FDA, or methods that give statistically equivalent results to the FDA methods, for which the analyst has been approved, unless excused for due cause. The laboratory tests and recommended duplicates of samples are shown in Table 1, page 25.

### **WATER MICROBIOLOGY**

Laboratories using EPA or State administered programs for water analysis are not required to meet the intentions of this Section. State administered programs include central, official, officially designated and other water testing laboratories sanctioned by the state and participation in a split sample program is voluntary.

Each State central accredited milk laboratory, and all State official, officially designated accredited milk laboratories not participating in an EPA or State administered program for water analysis shall participate annually in a microbiological proficiency testing program for each water analysis methodology for which the laboratory is certified. The proficiency testing samples are to be provided by State programs or through private providers.

An acceptable annual proficiency testing program shall meet the following applicable criteria:

1. When a laboratory examines dairy water for the presence of coliforms, a minimum of eight (8) samples shall be examined by the laboratory using those procedures for which the laboratory has been approved unless excused for due cause. The laboratory tests, categories, types and recommended duplicates are shown in Table 1, page 25.

### **SPLIT SAMPLE ANALYSIS**

The multiple tube fermentation (Lauryl Tryptose Broth or Chromogenic substrate), membrane filtration and heterotrophic plate count result of each laboratory shall fall within the limits shown in Table 2, page 26.

The steps for statistical analysis of split sample results are as follows:

1. A minimum of ten (10) results per sample per test is required for statistical analysis.
2. Calculate the logarithmic mean for the multiple tube fermentation, membrane filtration and heterotrophic plate count for each test sample; using a table of common logarithms, list the logarithms of all counts for a given sample. Calculate the mean of the logarithms for the sample.

3. Determine for each sample for each test whether there are results outside of the Rejection Limit ( $L_1$ ). Rejection results are identified by applying to each laboratory's result the limit (sample mean  $\pm L_1$ ). Results falling outside the limit are classified as outliers and are unacceptable. (Note by sample and test, the laboratories that have results outside of the limits.)
4. Determine for each sample for each test whether there are laboratory results outside of the Rejection Limit ( $L_2$ ). Remove unacceptable laboratory results and re-compute the mean of each sample if results have been rejected in accordance with 3 above. If there are none, use the same means calculated in 2 or 3 above. Rejection results are identified by applying to each laboratory's result the limit (sample mean  $\pm L_2$ ). Results falling outside the limit are classified as "out of limits" and are unacceptable. (Note by sample and test, the laboratories that have results outside of these limits.)
5. Using Table 3, page 26, list all laboratories that have more than the maximum number of sample results per test classified as unacceptable by either the  $L_1$  or  $L_2$  or both limits.
6. Laboratories accredited for dairy water analysis shall meet the acceptance limits ( $L_1$  and  $L_2$ ) and performance levels shown in Tables 2 and 3, page 26.

#### **LABORATORY PERFORMANCE LEVEL**

Laboratories accredited to perform the examinations of dairy water for coliforms required by the PMO shall meet the following performance levels on an annual basis.

1. Laboratories accredited to perform the multiple tube fermentation, membrane filtration, heterotrophic plate count and chromogenic substrate analysis shall meet the acceptance limits and performance levels shown in Tables 2 and 3, page 26.
2. Laboratories accredited for presence-absence procedures shall qualitatively detect and verify coliform organisms in samples containing coliform organisms.

Fully accredited laboratories not meeting the described performance levels shall be provisionally accredited for the test procedure(s) in which they exceed the maximum number of unacceptable results on samples. Provisionally accredited laboratories can regain full accreditation status by meeting satisfactory performance levels on the next set of split samples. If a provisionally accredited laboratory does not meet satisfactory performance levels on the next set of split samples, accreditation to perform the specific test(s) will be withdrawn. A laboratory that has lost accreditation must participate in a training program acceptable to the milk laboratory certifying authority before requesting reaccreditation. Re-accreditation after training shall be based on the laboratory meeting the accreditation criteria described in SECTION 1: LABORATORY EVALUATION PROGRAMS.

Copies of the proficiency testing report, including tabulation of laboratory results, shall be sent within four (4) months of the split sample examination date to the participating laboratory, the appropriate Food and Drug Administration Regional Office, and the FDA/LPET.

### **SECTION 3: CERTIFICATION OF LABORATORY EVALUATION OFFICERS**

Initial certification of State LEO shall be based on meeting the following criteria:

1. The individual must be a State government employee and demonstrate competence in evaluating milk testing laboratories and analysts' performance of milk laboratory test methods or Appendix N procedures as stated on the FDA-2400 Series Forms, and where appropriate, as described in SMEDP when accompanied by a representative of the FDA/LPET on an initial check laboratory evaluation. Initial check evaluation surveys (for certification) should not be conducted at sites that have been evaluated within the past 90 days.
2. The individual must submit an acceptable written report of the milk laboratory initial check evaluation to the FDA/LPET within 60 days of the evaluation.
3. The individual must attend the Milk Laboratory Evaluation Officers Workshop (FDA Course #373) conducted by the FDA/LPET in conjunction with the Food and Drug Administration, State Training Team. Note: It is recommended that the individual attend the Milk Laboratory Evaluation Officers Workshop prior to step 1 above.

Laboratory evaluations conducted by conditionally approved State LEOs are official.

Conditional certification of a State LEO can occur following the initial check evaluation described above. Full certification will be granted after the State LEO attends the next scheduled Milk Laboratory Evaluation Officers Workshop. Failure of a conditionally certified State LEO to attend the next scheduled Workshop, unless excused with cause by FDA/LPET, will require that the State LEO must restart the process. The State LEO candidate would then be required to participate in another check evaluation with a representative of the FDA/LPET, and then attend the next scheduled Workshop.

Recertification of the State LEO will occur triennially, and will be based on satisfactorily meeting the following criteria:

1. The individual must be a State government employee and demonstrate continued competence in evaluating milk testing laboratories and analysts' performance of milk laboratory test methods or Appendix N procedures as stated on the FDA-2400 Series Forms, and where appropriate, as described in SMEDP when accompanied by a representative of the FDA/LPET on a check laboratory evaluation.
2. The individual must submit an acceptable written report of the milk laboratory check evaluation to the FDA/LPET within 60 days of the evaluation.
3. The individual must have all laboratory evaluations, proficiency test examinations, and reports current (in particular biennial surveys must be performed within the month of their anniversary date).

4. The individual must have prepared and transmitted, at least annually, a summary list of certified and approved analysts and procedures by laboratory to the state milk sanitation rating agency and the FDA/LPET.
5. The individual has met the responsibilities for the training of Industry Supervisors.
6. The individual must attend the Milk Laboratory Evaluation Officers Workshop once every three (3) years.
7. The individual must not fail, without cause, to attend an FDA Regional Milk Seminar. If a region holds a FDA Regional Milk Seminar, then State LEOs in that region are obligated to attend. If another region holds their milk seminar in the same year the State LEO may opt to attend that seminar in lieu of attending the seminar held in their region and still meet the requirement.

Once an individual has become a State LEO and is therefore considered fully certified, if he/she fails to submit acceptable written reports of milk laboratory evaluations within 60 days to the FDA/LPET or fails to comply with item 2 above for Recertification (or continued certification), the State LEO will have their certification status downgraded from full to provisional. In addition, an action plan will be established that is mutually agreeable to the FDA/LPET and the state. The State LEO would have to meet the action plan criteria in addition to continuing to meet all the criteria specified in items 1-7 above, to maintain provisional certification status.

Laboratory evaluations conducted by provisionally approved State LEOs are official.

Should a provisionally certified State LEO meet the criteria specified by their action plan and EML, SECTION 3, their certification will be returned to full certification once they have successfully undergone their next check evaluation with the FDA/LPET.

Should a provisionally certified State LEO fail to meet the criteria specified in EML, SECTION 3 and/or follow the action plan, then their certification would be revoked.

The procedures for revocation must follow SECTION V. QUALIFICATIONS AND CERTIFICATIONS, Part H. of the *Procedures* Document.

State LEOs who lose certification cannot be re-certified for a period of 60 days from the date of loss of certification. Recertification will require meeting the requirements for initial certification.

## **SECTION 4: EQUIPMENT AND APPARATUS OF AID TO EVALUATION OFFICERS**

While conducting laboratory evaluations, the State LEO may find it extremely useful to have in his/her possession different types of equipment which will enable them to examine the apparatus in use and judge the proficiency of laboratory procedures in use for the examination of milk products. Some evaluation officers currently use a large percentage of the equipment and apparatus listed below. Equipment should be maintained in proper working conditions to assure accuracy.

1. Brom thymol blue solution.
2. Chlorine test kit (chloramine or free chlorine).
3. Conductivity meter.
4. Anemometer
5. Level (or cross test level).
6. Light meter (in foot-candles).
7. Maximum registering thermometer (MRT) for autoclaves.
8. Reference books - other than SMEDP. (e.g., AOAC Official Methods of Analysis, Standard Methods for the Examination of Water and Wastewater)
9. Ruler, pocket - metric.
10. Special measuring flask (calibrated at 97-99-101-ml).
11. Taper gauge or drill bits for PLC loops.
12. Thermometer(s).
13. Weights - accurate (S/S1 or ASTM 1, 2 or 3).

## **SECTION 5: GUIDELINES FOR CONDUCTING LABORATORY EVALUATIONS**

The evaluations of laboratories by a State LEO should be systematic. These guidelines are recommended to enable complete evaluation of the laboratory facilities, equipment and records and of analyst technique.

Upon initial evaluation and/or renewal, the laboratory, must make application for an evaluation upon a form provided by the State LEO. The application will include the statement:

**“I AGREE TO THE PROVISIONS OF THE NCIMS AND THE PROCEDURES FOR THE EVALUATION OF MILK LABORATORIES.”**

In preparation for the laboratory evaluation, normally the laboratory director or supervisor should be notified in advance to insure the presence of analysts and the availability of samples for laboratory examination. In arranging for an initial evaluation, laboratory officials should be told that all tests must be set up and that during the evaluation the work of all analysts, who may perform any official methods must be observed. If laboratory evaluations are conducted on days when procedures, e.g. the SPC, are not normally performed, advance arrangements should be made to have samples on hand in order to observe the SPC procedure and the laboratory personnel should be requested to save countable plates from the previous day. Where the latter is not feasible, previously prepared and incubated plates may be brought to the laboratory by the State LEO to permit observations of counting procedures.

On the designated laboratory evaluation day, delay arrival at the laboratory/facility until 10 - 15 minutes after the opening of the laboratory, to allow all personnel to start their day's activities normally. A visit to the laboratory director and/or supervisor's office should be made prior to entering the laboratory. At this time the purpose of the evaluation should be reviewed, and arrangements made to discuss the completed laboratory evaluation informally with the laboratory director and/or supervisors on completion of the evaluation. Assure that the “Grade ‘A’ Milk Laboratory Evaluation Request and Agreement Form” has been signed by a representative of the facility.

After entering the laboratory, the State LEO should note the names of all analysts in laboratory as/or after they are introduced and record procedures performed by each.

Before beginning the survey, the State LEO should discuss the “ground rules” for the survey. Rules should be established for procedural evaluations (e.g. whether an analyst can restart a procedure if the analyst notices that he/she make an error, how many times may an analyst restart...).

During an evaluation of a large laboratory, various analysts may be performing different examinations which may make a comprehensive evaluation difficult, particularly since all analysts are to be observed for each bacteriological and chemical procedure for which certification is requested. It is recommended that the officer establish a schedule so as to be in a position to evaluate apparatus and procedures used in the laboratory without disrupting, as far as

possible, the routine examination of samples. Since it is expected that various portions of the evaluation forms will be used at separate times, it is advisable to note observed items of the various procedures on the left hand margins of the evaluation forms. By frequent referral to the noted items, the State LEO will be reminded to observe all laboratory procedures in use and avoid misuse of the phrase "undetermined" (U) when procedures were actually in use but were not observed.

While observations of procedures are being made and the evaluation forms completed, certain precautions should be taken by the State LEO:

1. Do not ask leading questions, e.g., do not ask analysts if plating media and dilution blanks are autoclaved at 120±1C for 15 minutes; simply ask how media and water blanks are autoclaved;
2. Try to keep the evaluation on an informal basis and to minimize nervousness on the part of analysts, e.g., do not over emphasize the evaluation of procedures by unusually close physical observation; and
3. Stay alert during the observation of procedures so as to avoid necessary requests to repeat a technique overlooked during a procedure.

During the laboratory evaluation it is probable that some items pertinent to receiving samples will not be observed. However, the State LEO should determine from consultation with the laboratory supervisor the procedures used in receiving samples from the sample collectors:

1. Do the samples arrive at the laboratory as specified in the appropriate FDA-2400 Series Forms?
2. Are the samples suitably identified as to date, temperature and time of pickup, identification of sampler (e.g. name or initials) and sample identification or this information is readily available?
3. Is an extra sample or pilot container of appropriate size provided as a temperature control (TC)?
4. Are the raw milk sample containers no more than three-quarters (3/4) full?
5. Are samples ever rejected because they are outside of the acceptable temperature range at the time of pick-up from a sample storage depot or arrival at the laboratory, are samples ever rejected because they are too full or not properly identified?
6. How many hours pass (from initial time of collection of samples) before samples are plated?

Deviations are to be discussed with the analysts at some time after it has been observed and properly recorded. This discussion should include the nature of the deviation, any effect on validity of results, remedial action suggested and reasons justifying the change. All interested

personnel should have an opportunity to look over the completed evaluation form and each major deviation should be discussed by the officer with interested staff. At that time comments should be invited from the staff concerning the evaluation. The State LEO should make suggestions concerning any needed improvement of laboratory techniques. Following the discussion of procedures and competence of analysts, past split sample results of the laboratory should be discussed, suggestions made for improvement, and/or commendations made for superior performance.

In addition to a regularly scheduled visit, some State LEOs find that an occasional unannounced visit to an accredited laboratory provides them with supporting information concerning laboratory practices. Information generated on all surveys (unannounced, scheduled, check surveys) must be evaluated by the State LEO and used to determine compliance to the NCIMS Milk Laboratory Program.

If at any time during any evaluation there is interference with or willful refusal to permit evaluation, the State LEO will serve notice that the laboratory will not be certified or will be decertified until such time as the laboratory agrees to abide by the voluntary certification program. The laboratory may make reapplication by completing the application form and stipulating that future interference or refusals will result in non-certification or decertification for thirty days (30). Or, if at any time before or during any evaluation the State LEO feels their safety is in jeopardy or determines extensive non-compliance, they may terminate the evaluation. The State LEO must indicate to the laboratory management why the evaluation was terminated and must indicate what steps must be taken before a re-evaluation will be scheduled. The laboratory may make reapplication by addressing the concerns that led to the termination of the evaluation and by completing the application form and stipulating that the safety concerns and/or non compliance issues have been addressed.



## **SECTION 6: LABORATORY EVALUATION REPORTS**

### **EVALUATION FORMS**

FDA-2400 Series Forms shall be completely identified with the name of the laboratory, the laboratory number, its location, date and the name of the individual making the evaluation (even when pages are stapled together they may become separated during handling or filing). Forms pertaining to procedures not used should not be returned with the report.

Copies of the evaluation forms are to be prepared for the laboratory evaluated. The State LEO must maintain a complete copy of the evaluation report, including forms. The laboratory/facility and State LEO must maintain, at minimum, copies of the last two biennial/triennial evaluations, subject to verification by the State LEO and the FDA/LPET. In marking the official copies of the completed evaluation forms, leave items in compliance blank. When typing copies for transmittal to others, do not include check marks in the margin which were made at the time of the actual evaluation for the convenience of the evaluating official.

### **NARRATIVE REPORT**

The set of completed evaluation forms for the laboratory must be accompanied by a narrative report giving the conclusions of the State LEO as to whether or not the laboratory is doing acceptable work. Additional narrative reports, without FDA-2400 Series Forms, are to be sent to others that need to be informed as to the outcome of the laboratory evaluation. State LEOs may submit reports by email, however, they must receive verification of receipt by return email and must maintain a copy of the verification in their records. The narrative report must identify the laboratory, give the laboratory number, show the date of the evaluation, who made the evaluation, list the prior status, list the date of the last on-site evaluation, indicate the present status, what recommendations were made to correct any deviations, what test were approved, and who was certified to do them.

The report must be sufficiently detailed to allow readers to determine what is being cited without having to refer to the FDA-2400 Series Forms.

A form suitable for narrative reports appears on pages 27 - 32.

Grouped under the title of each method observed (e.g., Standard Plate Count), list each major and/or minor deviation or omission numbered identically with the item number on the evaluation form and the corrective action necessary for compliance with standard procedures or good laboratory practices.

A paragraph headed "Remarks" or "Recommendations" may be included if the officer wishes to comment on an item, e.g., one which could be improved by a change in procedure or by new equipment, or for any comment which is not appropriately covered in other Sections of the report.

After "Personnel and Procedures Certified" list the full name of all laboratory personnel qualified to make each individual test for which certification or approval is given. Include information on the analysts' last split sample performance. Also include a statement requiring participation in the Proficiency Testing Program to maintain certification (e.g., "To maintain certification, analysts must successfully participate in the Annual Proficiency Testing Program for all procedures for which certification has been granted").

Demonstrated proficiency or outstanding ability of individuals for one or more procedures which deserve special commendation may be given after the side heading "Commendations". If no commendation is warranted, delete this side heading from the narrative report. Such commendations should be used for outstanding performance.

Under "Conclusion" give a descriptive statement of the degree of acceptability or rejection of the procedures used by the laboratory, including recommendations for approval or rejection of the results of the laboratory. Some typical conclusions are given in the following text, and except in special circumstances, one of the conclusions listed must be used to indicate whether the results are (or are not) acceptable to State authorities for use in rating milk for interstate shipment, where this is the purpose of the evaluation.

## CONCLUSIONS

1. This laboratory is accredited/approved as the procedures, records, facilities and equipment in use at the time of the evaluation were in compliance with the requirements of the *Grade 'A' PMO*.

Explanation: Unqualified acceptance of the laboratory.

2. Although the procedures, records, facilities and/or equipment in use at the time of the evaluation were in substantial compliance with the requirements of the *Grade 'A' PMO* the analyst/facility/equipment/records deviations noted must be corrected. This laboratory is accredited/approved for 30 - 60 days pending correction of the deviations and receipt of a letter by the evaluation officer detailing the corrections made. Upon receipt of such letter, full accreditation/approval will be given.

Explanation: A qualified acceptance where the State LEO believes that the deviations noted do not seriously affect the analytical results and that a letter explaining the corrective actions taken will be sufficient to ensure compliance.

3. Although the procedures, records, facilities and/or equipment in use at the time of the evaluation did not substantially comply with the requirements of the *Grade 'A' PMO*, the analyst/facility/equipment/records deviations noted are readily correctable. This laboratory is accredited/approved for (\_\_\_) days pending correction of the deviations. Corrections must be made and detailed in writing to the evaluation officer during this period. A new evaluation will be scheduled upon receipt of the letter to assure full compliance.

Explanation: A qualified acceptance where procedural or technical errors or facilities which could have an effect on analytical results are noted but which are readily correctable by the analysts or management. Depending on the judgment of the State LEO, a period of no more than 60 days usually is given to make the required adjustments before another evaluation is made or specified criteria are met, record, new equipment, etc. (some things may not require a return visit) to fully accredit (or approve) the laboratory.

4. This laboratory is not accredited/approved as the procedures, records, facilities and/or equipment in use at the time of the evaluation did not comply with the requirements of the *Grade 'A' PMO*".

Explanation: Severe deficiencies in facilities, records, staff and/or procedural techniques exist which would result in unacceptable results. A new on-site evaluation shall be made when the State LEO has reason to believe that a rating would result in an acceptable rating. A new on-site evaluation would not be required for certified milk laboratories, CIS facility or screening facilities if the withdrawal was for facility deficiencies only. The laboratory, CIS facility or screening facility would be required to submit pictures, invoices, etc. to show compliance with the facility requirements noted in the last on-site evaluation.

## REFERENCES

1. Available from the American Public Health Association, 800 I St., N.W., Washington, D.C. 20001-3710, USA. {<http://www.apha.org>}
2. Copies of the FDA-2400 Series Forms can be downloaded from {<http://www.fda.gov/opacom/morechoices/fdaforms/default.html>}

**TABLE 1**

<u>PRODUCTS</u>	<u>NUMBER OF SAMPLES</u>	<u>DUPLICATES</u>	<u>ANALYSIS</u>	<u>NUMBER OF PRODUCT SAMPLES ANALYZED</u>
HVD, or 2%, or Skim	3	1	Plate Count /Coliforms	3
			Phosphatase	1
			Vitamins	3
Cream, heavy	2	1	Plate Count /Coliforms	2
			Phosphatase	2
			Vitamins	2
Cream, light	2 <sup>a</sup>	0 or 1	Plate Count /Coliforms	1
			Phosphatase	2 <sup>b</sup>
			Vitamins	1
Chocolate	2	1	Plate Count /Coliforms	2
			Phosphatase	1
			Vitamins	2
Raw	6	3	Plate Count	6
Raw	8	4	Inhibitors	8
			Somatic Cells	8
			Added Water <sup>c</sup>	8
Dairy Water	8	4	Coliforms	8
			Heterotrophic Plate Count	8
Milk Totals	23 <sup>a</sup>	10 or 11	Plate Count	14
			Coliforms	8
			Phosphatase	6
			Vitamins	8
			Inhibitors	8
			Somatic Cells	8
Dairy Water Total	8	4	Coliforms	8
			Heterotrophic Plate Count	8

a - One of these samples serves as the temperature control (TC).

b - These two (2) samples are tested for both residual and reactivated phosphatase

c - This analysis is optional.

**TABLE 2**

<b><u>TEST</u></b>	<b><u>REJECTION LIMIT 1</u></b> <b><u>(L<sub>1</sub>)*</u></b>	<b><u>REJECTION LIMIT 2</u></b> <b><u>(L<sub>2</sub>)*</u></b>
Plate Counts	0.268	0.179
Direct Somatic Cell Count	0.300	0.200
Electronic Somatic Cell Count	0.212	0.143
Vitamins	0.300	0.200
Electronic Phosphatase Count	0.300	0.200
Dairy water MPN	0.949	0.632
Heterotrophic Plate Count	0.300	0.200

\* To be used with logarithmic mean.

**TABLE 3**

<b><u>NUMBER OF RESULTS PER TEST</u></b> <b><u>(N)</u></b>	<b><u>MAXIMUM NUMBER OF</u></b> <b><u>UNACCEPTABLE RESULTS PER</u></b> <b><u>TEST FOR APPROVAL</u></b>
5 – 10	1
11 – 20	2
21 – 30	3

## **EXAMPLE**

Report of a Biennial On-Site Evaluation

of

Certified Industry Supervisor  
Name  
Plant Manager

Laboratory Name  
Laboratory number: 00600  
Laboratory Street Address  
City, State 00000

On

Evaluation Date

By

LEO Name  
Laboratory Evaluation Officer

Last Certified: Date

A copy of the "Grade 'A' Milk Laboratory Evaluation Request and Agreement Form" is signed and is on file.

Previous Laboratory Status: Fully certified for [List Procedures].

Present Laboratory Status: Fully certified for [List Procedures] pending receipt within 60 days of correction of deviations resulting from on - site evaluation of [Date].

Other changes that need to be made to IMS list, etc: None or List Changes

The following is a summary of the recent evaluation of your milk laboratory in accordance with the requirements of the Grade 'A' PMO. Deviated items are marked with an "X" on the evaluation forms. Items marked "U" are undetermined because of local conditions at the time of the evaluation. Laboratory procedures and/or equipment marked "O" are not used. Items marked "NA" are optional procedural techniques and/or equipment not applicable to designated laboratory procedures. Repeat deviations are marked by an asterisk "\*". Noted items are not considered deviations. They will be marked as deviations if not corrected by the next evaluation.

Beta lactam Tests

DEVIATIONS AND CORRECTIONS

GENERAL REQUIREMENTS

3. Thermometers for use with Test Kits and Laboratory Equipment.
- d. Calibrate your freezer thermometer against a traceable thermometer.
- d2. Tag above calibrated thermometer with date, identification and correction (+0.0, if none) and record results.
6. Balance.
- e. Note: Have your new balance calibrated annually by a qualified service representative.

TECHNIQUES

[Name Test]

No deviations were observed for the [Name Test].

[Name of Second Test]

15. Test Procedure.
- p. Multiple tests were run at the same time. Start incubation timing immediately after the sample is added to the last test device. Analyst started timing too late.

CONCLUSIONS

[CIS Name] is certified as a Certified Industry Supervisor to perform the procedures as listed above pending correction of listed deviations and receipt of corrections in writing by the State LEO within sixty days of receipt of this evaluation. Contact me if there are questions.

Sincerely,

LEO Name  
Laboratory Evaluation Officer

## **EXAMPLE REPORT**

REPORT Of an On-Site Biennial/  
Supplemental (analyst, procedure, walk-through)/  
Unofficial

Certified Laboratory  
NCIMS Lab ##

Certified Industry Supervisor  
CIS ##

Appendix N Screening Site

NAME OF SITE  
Address  
Date of evaluation  
By LEO's name

Previous Laboratory Status: Fully/provisionally/conditionally Certified until date  
Previous Procedures: X, X, X

Present Laboratory Status: Fully/provisionally/conditionally Certified until date, pending  
acceptable response to this report  
Procedures evaluated: X, X

A copy of the "Grade 'A' Milk Laboratory Evaluation Request and Agreement Form" is signed  
and is on file with LEO.

Other changes that need to be made to IMS list, etc: None

The following is a summary of the recent evaluation of your milk laboratory in accordance with  
the requirements of the Grade 'A' PMO. Deviated items are marked with an "X" on the  
evaluation forms. Items marked "U" are undetermined because of local conditions at the time of  
the evaluation. Laboratory procedures and/or equipment marked "O" are not used. Items  
marked "NA" are optional procedural techniques and/or equipment not applicable to designated  
laboratory procedures. Repeat deviations are marked by an asterisk "\*". Noted items are not  
considered deviations. They will be marked as deviations if not corrected by the next evaluation.



DEVIATIONS AND CORRECTIVE ACTIONS

ITEM

METHOD

CULTURAL PROCEDURES FOR CERTIFIED LAB/  
GENERAL REQUIREMENTS FOR APP N

**CERTIFIED LAB**

- 3d1. In the media section, calibration of thermometers was done but the calibration temperature was not always at temperature of use. Refrigerator was calibrated at 5C vs. 0.0C and hot air oven was calibrated at 65C vs. 170C. Send new/proper calibrations with response.
- 3d2a. The tags did not include correction factors in media area. Send verification.

**APPENDIX N LAB**

*1c. Adequate lighting, [NCIMS Certified Laboratories, and Certified Industry Supervisors >50 foot candles at the working surface (pref. 100)].*

During the technique demonstration, the wall light was not used. The lighting measured 14-24 foot candles in the confirmation testing area. The confirmation testing area had 83-105 foot candles when the wall light was utilized. Whenever testing is being conducted the wall light must be utilized.

It was determined during the survey that the screening test area had 20-25 foot candles of light. Add additional lighting to the area to increase to >50 ft-candles and send verification.

ITEM

METHOD

TESTS-LIST ALL TESTS OBSERVED and DEVIATIONS OF TECHNIQUES.

**CERTIFIED LAB**

Standard Plate Count, Coliform, and Simplified Count Methods

- 5b1/2. Proper mixing or shaking of samples, retail must have complete inversion top over bottom and raw is to be more vigorous than observed.
- 6d. Analysts are to avoid the foam of sample. The raw milk container may be tapped on the container on counter and tilted as to show clear spot on surface of milk. The pipet is not inserted more than 2.5 cm. Analysts may use the cap of retail containers or sterile Petri dish to adjust the pipet volume and not adjust pipet volume while pipet is still in liquid portion of sample.

## **APPENDIX N LAB**

*3a1. Incubator level. Temperature checked daily (day of use), records maintained.*

The temperature is not being recorded to the tenth of a degree. Please instruct analysts to record the strip incubator to the tenth of a degree.

*10a. Reader tapes or computer printouts maintained for two years.*

Please remember that the kit number is the lot number. Please Note: Post the analyst codes in each testing area (confirmation testing area and screening testing area). This will eliminate any confusion as to which code belongs to which analyst.

Comments/Recommendations: Optional Areas that may need to be addressed or LEO has some concern.

PERSONNEL AND PROCEDURES CERTIFIED

LEO IS TO LIST ALL THE PERSONNEL AND PROCEDURES THAT WERE EVALUATED AT THIS AUDIT. INCLUDE A LETTER (X, C, N, ETC) THAT DENOTES THE STATUS OF ANALYSTS (REFERENCED AS BELOW) ON THE EVALUATION AND SPLIT SAMPLES.

**CERTIFIED LAB**

PERSONNEL AND PROCEDURES CERTIFIED

	SPC/PACCOLI/PCCPMC	D3	II	C <sup>3,9,10,12</sup>	DMSCC	PHOS <sup>28</sup>
Name Analyst 1	X/N	X/X	X	C	X	X
Name Analyst 2	X/P	X/X	X	X	X	X

[X denotes full certification in the indicated procedures pending acceptable performance in the annual proficiency testing program (split sample) for all procedures for which certification has been granted. P denotes provisional certification pending acceptable performance in the annual proficiency testing program for all procedures for which certification has been granted. C denotes conditional certification pending acceptable performance in the annual proficiency testing program for all procedures for which certification has been granted. N denotes no certification status granted.].

**APPENDIX N LAB**

Certified Industry Analysts	2004 On-Site Evaluation TEST KIT	4/2004 Split Sample Survey TEST KIT
Name CIS 1	x (CIS)	x
Name CIS 2	x (CIS)	x
Name CIS 3	No Longer Employed	x
Industry Analysts	2004 On-Site Evaluation TEST KIT	6/2004 Split Sample Survey TEST KIT
Name IA 1	x	x
Name IA 2	x	x

CONCLUSION

Use the proper conclusion found on pages 23 & 24.